



# AMERICAN CAR CRAFT INSTRUCTIONS

## C6 Corvette 4pc Retro Fender Spears Part #042116



### **PARTS INCLUDED:**

- 4-Chrome ABS Spears
- 2-Packs of Adhesive Promoter
- 1-Paper Template
- 2-12" of 1/4" Chrome Trim (Optional)

The new retro spear kit contains four spears, two for each side. They are designed to set into the vent opening offering an extended look for the fender as well as a very cool overall retro look with a slightly modern finish. The spears are very easy to install by any one and have been time tested to endure the elements.

1. The preparation of the paint surface is the key for this product and will determine the success of this installation. The first step will be to thoroughly scrub the paint surface in front of the vent opening with alcohol. Scrub the area several times to insure that all waxes and or paint treatments are completely removed. Test this by applying some masking tape to determine the level of tack you have accomplished.
2. You have been provided with a paper template for the spear placement. Cut this template along the dotted line and cut out the square holes. Place the prepared template at the fender edge as well as the edge of the vent opening and secure the template in place by applying small segments of masking tape over each of the square holes
3. With the template nicely taped in place swipe the two spear areas with the adhesive promoter provided and allow it to dry for a few seconds. Each of the spears is identified with a description for its location: Driver Top/Driver bottom etc. Before you permanently attach any spear, place the correct spear in its location to familiarize yourself with its position as well as how level it will be. Once you have this clear in your mind simply peel the red release liner from the back of the spear and carefully set it in place pressing firmly to set its position. After you have successfully set the second spear carefully remove the template so that you can reuse it for the other side and follow the exact same procedures. Allow twenty four hours to set before washing the vehicle. Pressure washing is NOT recommended.
4. **Optional Step:** You have been supplied with two lengths of chrome trim. This trim has been supplied to be placed at the outer edge of the vent opening to add a nice finished appearance. Simply clean the vent ridge with household rubbing alcohol then swipe with the adhesive promoter provided. Once preparation is complete simply peel the red release liner from the precut trim and set in place. Press firmly to set.

**Thank you and enjoy your purchase!**

**If any questions occur during installation please contact**

**AMERICAN CAR CRAFT**

**18924 SAKERA ROAD-HUDSON FLORIDA 34667**

**Phone # 727-861-1500**

**Fax # 727-861-1520**

**[www.americancarcraft.com](http://www.americancarcraft.com)**